ChangZhou Smart-Lifesciences Biotechnology Co., Ltd.
Hotline Service: 0086-519-83820182 **E-mail:**sales@smart-lifesciences.com
West Taihu science and Technology Industrial Park,Wujin District,Changzhou City,Jiangsu Province,China

lexCap Smac Q

Index

1. Product Description.....1
2. Purification Procedure.....1
3. Cleaning-in-Place.....2
4. Troubleshooting.....2
5. Related Products.....2

1. Product Description

Ion exchange resins are widely used in biomedical and bioengineering for separation and purification of proteins, nucleic acids and polypeptides.**Smac Q** based on a highly rigid agarose base matrix that offers outstanding pressure/flow properties, optimized pore structure,and very high chemical stability to support CIP procedures.

Smac Q is a strong anion exchange resin. The ion exchange group is a quaternary amine group.see below.

$-O-CH_2CHOHCH_2OCH_2CHOHCH_2N^+(CH_3)_3$

lexCap Smac Q is a prepacked ready to use column for purification. **lexCap Smac Q** 1ml and 5ml columns are packed with 1ml and 5ml of **Smac Q**. **lexCap Smac Q** can be operated with a peristaltic pump or liquid chromatography systems, such as ÄKTA. It is fast, simple and easy operation.

Table 1. Characteristics of **Smac Q**

Item	Description
Matrix	Highly cross-linked agarose
Ion exchange type	Strong anion
Ion exchange capacity	0.16-0.23 mmol Cl^-/ml medium
Particle Size	45-165 μm
Flow rate	< 700cm/h
pH stability	2-12
Storage buffer	20% ethanol
Storage	4℃- 30℃

2. Purification Procedure

2.1 Buffer Preparation

Water and chemicals used for buffer preparation should be high purity. It is recommended to filter the buffers by passing them through a 0.22μm or 0.45μm filter before use.

2.2 Sample Preparation

It is recommended to filter the sample solution by passing them through a 0.22μm or 0.45μm filter before use.

2.3 Sample Purification

1) Fill the pump tubing with binding buffer. Connect the column to purification system, “drop to drop” to avoid introducing air into the column.
2) Wash the column with 10 column volumes of binding buffer.
3) Apply the sample, using a syringe fitted to the connector or by pumping it onto the column.
4) Wash with 5 to 10 column volumes of binding buffer or until no material appears in the effluent.
5) Elute with Elution Buffer using a stepwise or linear gradient. For one-step elution, 5 column volumes are usually enough. Other volumes may be required if the interaction is difficult to break. Linear gradient elution can be used to separate proteins of different binding strengths with a small gradient, such as 20 column volumes or more.

2.4 Analysis

Identify the fractions containing the target protein. using UV absorbance, SDS-PAGE, or western blot.

3. Clean-in-Place

After each separation, elute any reversibly bound material either with a high ionic strength solution (e.g. 1M NaCl in buffer) or by increasing pH. Regenerate the media by washing with at least 5 bed volumes of buffer, or until the column effluent shows stable conductivity and pH values.

Cleaning-in-place (CIP) is a cleaning procedure that removes contaminants such as lipids, precipitates, or denatured proteins that may remain in the packed column after regeneration. Regular CIP also prevents the build-up of these contaminants in the media bed and helps to maintain the capacity, flow properties and general performance of the media.

A specific CIP protocol should be designed for each process according to the type of contaminants present. CIP cycle is generally recommended every 1-5 separation cycles.

Remove the ionically bound proteins

Wash with 3-4 column volumes of 2M NaCl. Contact time 10-15min.

Remove the precipitation or hydrophobically bound proteins or lipoproteins

Wash with at least 2 column volumes of 1M NaOH . Contact time 1-2h.

Remove lipids and very hydrophobic proteins

Wash with 2-4 column volumes of 0.5% non-ionic detergent,70% ethanol or 30% isopropanol. Contact time 1-2h.

4. Troubleshooting

Problem	Probable Cause	Solution
Back pressure is too high	Column is clogged	Cleaning in place(part 3).
	Sample solution contains precipitate	Filtering the sample solution by passing them through a 0.22μm or 0.45μm filter.
Eluate is not pure	The medium repeat too much times.	Cleaning in place(part 3).
	Wash is not enough.	Increase the volume of Wash Buffer.

5. Related Products

Product	Cat. No.	Size
Smac Q	SI019025	25 ml
	SI019100	100 ml
	SI019500	500 ml
	SI01901L	1 L
	SI01910L	10 L
IexCap Smac Q	SI019C11	1X1 ml
	SI019C51	5X1 ml
	SI019C15	1X5 ml
	SI019C55	5X5 ml